

AQUAFALL 300 / 600 / 900 1200 / 1500

(D) BEDIENUNGSANLEITUNG

(GB) OPERATING INSTRUCTIONS

(F) MODE D'EMPLOI


(I) ISTRUZIONI PER L'USO

(ES) INSTRUCCIONES PARA EL USO

(NL) GEBRUIKSAANWIJZING

(PL) INSTRUKCJA OBSŁUGI

**(PYS) ИНСТРУКЦИЯ ПО МОНТАЖУ
И ЭКСПЛУАТАЦИИ**





Art-Nr. 46200
Art-Nr. 46210
Art-Nr. 46220



Art-Nr. 46230
Art-Nr. 46240

seliger[®]
WATERPOWER

| | |
|--|----|
| AQUAFALL 300 / 600 - 46200 / 46210 | 4 |
| AQUAFALL 900 - 46220 | 8 |
| AQUAFALL 1200 - 46230 | 13 |
| AQUAFALL 1500 - 46240 | 18 |




AQUAFALL 300 / 600 - 46200 / 46210



AQUAFALL 300 / 600 - 46200 / 46210


A




1



2





3



4



5




B




1




2



3



4




AQUAFALL 300 / 600 - 46200 / 46210


C



1




2




3




4



5



6



AQUAFALL 300 / 600 - 46200 / 46210


D




1




2



3




4



5



6



AQUAFALL 900 - 46220

